

EP at DESY- study optimum parameters

You need infrastructure to study!! (Statistic)

It influences possible studies and results

Base line: How to start for building a new facility

### Apparatus

- Design (mechanic)
- Administration
- Sensors
- Acid
- Space

### Process Parameters

- Voltage /Current
- Temperature
- Field-flatness

# Design (mechanic)

DESY EP designed for

- Mono cells and cavities up to 2\*9 cell super-structure
- Designed according German laws applying for Hamburg
- Available space
  - No basement allowed (water pipes and drains below EP space)  
(➔sump + 2nd pump)
  - Height limited annex to building (clearance 1 inch on top)
- EP apparatus is an extension to the existing infrastructure
  - =>Limited space for acid storage
  - =>Limited quantity of rinsing water
  - =>Use of existing neutralization
  - =>location and connection to UPW and neutralization of rinsing water

## German laws applied for

Explosion safety → cabling + sensors + material

Need to

- Reduce explosion risk on the point of appearance ( Cavity )  
→ N2 Overlay and H2 sensor on point of appearance  
( + 70000\$ for explosion safe electric )
- Cavity has to be H2 leak tight
- Rotating shaft seal and gaskets to be controlled
- H2 / O2 not expected in drain acid H2 leaks on
- System (Cavity) at normal pressure

## Acid

- DESY EP is annex to the existing facility  
( reduced administration for license)

**Acid volume limited to a total of 250 Kg**

- single barrel ; No mixing station!
- External heat exchangers
- turn around industrial barrels
- Safety volume ( Housing has to hold 200 l acid)  
(Nomura plating 1t in basement container)

## **Ventilation**

- Exchange room volume 10 / hour → Size of housing + Gas scrubber

**HF gases** => no mixing allowed

→ total amount to be measured in 1200 l/h exhausting volume

Exhausting pipes located inside the work space area

→ Max HF concentration 1,7 ppm == Stop process

→ Max HF concentration >3 ppm stop apparatus

## **Safety**

- Definition of Sensors; Safety features
- personnel and infrastructure , containments

## **Rinsing water**

- DESY neutralization stand allows 200l per hour of Ph 1  
→ Reality 200 l of Ph 0 –0,2 from first rinse
- Dump of rinsing water by industrial company
- Control Ph value before personal entrance the housing



10/7/2005

A.Matheisen SMTF meeting

5



10/7/2005





10/7/2005



10/7/2005






10/7/2005



10/7/2005

10





Bottom view on acid pipes of DESY EP set up

10/7/2005

A.Matheisen SMTF meeting

11






Acid sump and feed back pump of DESY EP set up

10/7/2005

A.Matheisen SMTF meeting

12






10/7/2005

A.Matheisen SMTF meeting

13






10/7/2005

A.Matheisen SMTF meeting


14



10/7/2005

15





## My conclusion from that for the DESIGN is :

- Contact administration before start to design/ copy
  - ➔look what you can use /apply of existing design in parallel
- Define your need before start of design /copy
  - Look for space ( Copy of DESY design need adaptation )
  - Different space area can give some features (not applying at DESY)
  - Basement available => Number of pumps
  - Acid volume => integrated heat exchanger ( J lab )
  - Design 2\*9 cell may be optimized for 9 cell only  
( application for 9 cell cavities only changes turn point of apparatus)

This reduces time afterwards and reduces redesign / Stress

## After That

- Review different apparatus design and see what can be copied  
(Jlab /DESY / KEK / Numura plating / Henkel/Cornell)

# Sensors

**Number is defined by law and safety and process**

**HF sensors** commercial sensor's

calibration 2 times Year by official service

**H2 Sensors** commercial sensor's

calibration 2 times Year by official service

**Safety sensors**

Leak

Capacitive electronic sensors

High reliability high sensitivity applied for safety

Not applicable for level control etc

Level control

read relay sensors.

Empty - stop pump 2

Full - start pump 2

Max - stop pump 1 start pump 2

Overfilling Capacitive sensor- **Stop EP**



## **Acid Mixture 9/1 H<sub>2</sub>SO<sub>4</sub> /HF**

- process brings 6-8 KW heat to the acid for a 9 cell cavity

=>Temperature sensors

Temperature limit 35 C at 40 C (power supply off )

=>External single pass heat exchangers

designed for 20 KW for (2\*9 cell)

- Leakage control

Pipes and acid to water connection

- Safety regulation

Personal needs compressed air respirators +

Special closings for

Service / maintenance / repair and exchange of barrels

- Else ?


Safety department need instruction for emergency

coordination with fire brigade

training of personnel

extensive risk analysis for emergency and safety

# Process parameters/ Sensors and control



ELSE !



10/7/2005

21

## Material and equipment

- Commercial PVDF heat exchanger failed (Leak after 3 Month)  
(about 3000 welds /Material PVDF)
- Heat exchange rate too small (Thermal conductance of H<sub>2</sub>SO<sub>4</sub> low)
- PVDF not resistant
- Commercial HF gas scrubber failed better once too large
- Teflon heat exchanger tubes (0,8mm) wall thickness  
showed HF penetration to cooling water line
- Shaft seals made from Viton stand for 25h
- Shaft seals made from Teflon > 100h
- HF gas absorber : DESY uses granular absorbent (COSA D)

# HEAT EXCHANGER

OLD VERSION



10/7/2005

DESY VERSION




A.Matheisen SMTF meeting

23




## VERSION III



# ELECTRO POLISHING HEADS

## NEW VERSION



### Solutions:

quick locking mechanism

vertical level sensors

Drain now at bottom position  
during drain and rinse


## Advantage of the HF absorber opposite the gas scrubber and the lime milk cartridge

- The standard gas scrubber don't reduce HF-gas acceptable
- The lime milk cartridge has a very good absorb rate of HF but a high danger of a blockage of the cartridge
- The pressure fluctuations in the system are reduced with the HF absorber
- The HF absorb rate of HF absorber is good
- The danger of a blockage of the absorber cartridge is clearly smaller
- Changing of the granulates is simple



## Shaft seal (Viton) after 25 h of operation





PVDF tank after about 100h in operation



## Process Parameters

Constant Voltage  $\leftrightarrow$  Constant current

Optimum Voltage ?

Temperature 20C- 30C - 35C needs more investigation

Influence of T on results

Acid HF content (Mixture)


Design of electrode

Horizontal  $\leftrightarrow$  Vertical Polishing


Influence on Nb content in acid

	New acid (0 gr Nb/l)	Used acid (10-12 gr Nb/l)
voltage	17 [V]	17 [V]
current	320 [A]	210 [A]
Current density	5,81 [A/dm <sup>2</sup> ]	4,9 [A/dm <sup>2</sup> ]
oscillation	+44 – 66 [A]	+ 43 - 73[A]
Removal rate	0.445 [µm/min]	0,36 [µm/min]
Acid circulating	9-9,5 [l/min]	10-11 [l/min]
Acid injection speed per cell	5,3-5,6 [m/sec]	5,9-6,5 [m/sec]
Acid volume stored	150 [l]	140 [l]
HF content	2,78 [Mol/l]	~ 1,9 [Mol/l] Ref TPPT057
Nb content	0 [gr/l acid]	10-12 [gr/l acid]
Acid use time	0 [Minutes]	600 [Minutes]

## T4 average vs Eacc



## Cavity performance in respect to average Ep temperature



## Parameters of the DESY Ep Set Up

- EP acid mixture: sulfuric acid (96-98 %) / Hydrofluoric acid (48 %); volume factor 9/1
- HF gases: extreme strong out gassing of HF gases during system operation
- Solubility of Nb in EP acid: 10-12 gr / liter
- Removal rate: 0.4  $\mu\text{m}/\text{min}$  (average) at V 15-18 V**
- Current density: 9 cell cavity 5,47 A /dm<sup>2</sup> (average)**
- Removal distribution Iris equator : iris 1,7 times higher removal than equator  
(G.Kreps MHF-sl)
- Oscillation reduction with amount on deluted niobium in the acid and reduced HF**
- Current: stronger dependency on acid volume and outlet temperature than on gradient In/out  
typical values of 9 Amps /deg.C






Figure 4: Removal rates and aging of the EP Mixture HF/H<sub>2</sub>SO<sub>4</sub> (1/9). Removal rates measured for U=17V constant voltage.







## DESY control of EP Parameters

Process control by on line monitoring current and Temperature

Not stable parameters

Temperature

acid circulation (f [T])

HF content

Current (f [T;QHF])


Reference measurements by Polarimetry (U/I)


Temperature stable


Defined HF /Nb content




## U/I Curve measured on samples /test device











## Conclusion

No clear parameter set available/ seen yet  
at the DESY Infrastructure


➔ More studies on optimum parameter  
DESY task = stabilize T and HF content

Reduce number of variables to get parameter

- Temperature
- Mixture/ HF content  
to be tested on single cells ???
- Sulfur sedimentation
- actually unknown is influence of ??

More online process parameters need to be observed

➔ Install Integrated U-I sampler from the beginning  
(see Jlab)



## Monitoring the EP run of a 9 cell cavity

10/7/2005

A.Matheisen SMTF meeting

42



## Acid mixing / transport and storage

We learned that acid mixture is not acid mixture !!

Actually first results on “COMPOSITION”



- But Cavity result looked good (candidate for 35 MV/m )
- But U- I measurements look fine
- But standard analysis “titration of acid “ looked fine
- Apparatus stopped because HF exhausting >>>3ppm after 35 min

We expect written down information by end of October

My Summery of this is

- We need to have acid quality management
- We need to define the instruments for analysis of EP
- I would like to understand what the chemical reactions are that we use for EP ( a new parameter ??? )

From that it may become clearer which parameters are the once needed for high gradient

Exchange of knowledge

to be continued